


# Entry, Descent, and Landing Systems Short Course

Subject: Modular Honeycomb-Packed Polymer Based Ablative Heatshields  
Author: William M. Congdon, Director  
ARA Ablatives Laboratory

sponsored by  
International Planetary Probe Workshop 10  
June 15-16, 2013  
San Jose, California



EDL TECHNOLOGY SHORT COURSE  
INTERNATIONAL PLANETARY PROBE WORKSHOP-10  
SAN JOSE, CALIFORNIA – 15-21 JUNE 2013

# MODULAR HONEYCOMB-PACKED POLYMER-BASED ABLATIVE HEATSHIELDS (2.65-m MANUFACTURING DEMONSTRATION UNIT)



## Principal Investigator:

William M. Congdon  
ARA Ablatives Laboratory (ABL)  
Applied Research Associates  
Centennial, Colorado 80112  
303 / 699-7737

NASA ISPT Contract NNM07AA93C

# EXAMPLES OF CONSTITUENTS FOR CHARRING ABLATOR MATERIALS



Polymer Resin






Carbon Fiber



Silica Fiber



SiC Fiber




Phenolic MB



Carbon MB



Silica MB




70-100  $\mu\text{m}$

Also Ground Cork



## ABLATOR REINFORCING HONEYCOMB – LAB PRODUCTION AT ABL

**Standard H/C for ARA Ablators is 1.0-In. Cell Size, Large-Cell, Quartz Honeycomb  
(Also: Different Cell Size, Different Fabric Thickness, Different Fabric Materials)**





## TYPICAL PRODUCTION COMPOUNDING OF POLYMER-BASED ABLATOR


Ablator Compounds Contain Resin, Chopped Fibers, Microballoons, Other Fillers, and Special Additives





## MIXED COMPOUND NEEDS TO BE CHOPPED, SPREAD THIN, AND DRIED

Ablator Compounds Contain Solvents that Require Removal Via Chopping Plus Air or Oven Drying





## EXAMPLE MODULAR PACKING – 2.65-m AS SRAM-20 NOSE MODULE

From Start-to-Finish, Complete Packing Operation is a 7-hr Task for Two Packers Plus One Assistant  
Ablator Compound is Mixed/Processed the Day Before and “Frozen” – Honeycomb Pre-Fitted to Mold



End of Packing – Mold in Oven  
Under Vacuum-Bag Pressure

## 2.65-m SRAM-20 MDU HEATSHIELD PRODUCED VIA NINE MODULES

Ablative Thicker, Denser, More Robust than Honeycomb-Packed Ablator of Other Mars Missions  
Heatshield Final Thickness 1.25 in. – Produced to 1.40-in. Thickness with 0.25-in. Compound Overpack



18 Mix Batches Required for 2.65-m Heatshield

Module Type	Compound Mass	Mixed Bulk Volume	Mixed Bulk Volume	Drying Trays
Flank No.1	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.2	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.3	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.4	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.5	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.6	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.7	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Flank No.8	12,205 g	30 gal	4.01 ft <sup>3</sup>	60
Nose Part	12,502 g	31 gal	4.14 ft <sup>3</sup>	62
<b>Totals</b>	<b>110.14 kg</b>	<b>271 gal</b>	<b>36.2 ft<sup>3</sup></b>	<b>542</b>



## CONVENTIONAL PACKING NOT WORKABLE FOR LARGE HEATSHIELDS

### Modular Ablator Manufacturing Enables Large Robust Heatshields (with Greater Quality)

#### Conventional Production – Difficulties for Large Heatshields

- Robust Heatshields Require Denser/Thicker Ablators
- **Ablator Compounds Have Limited Working Life/Time**
- Denser Ablators Require More Packing Effort/Time
- Thicker Ablators Require More Packing Effort/Time
- **Too Many “Packers” Causes Process Interference**
- Too Many Packers Needed to Meet Time Constraints

#### **Packing Has Stringent Time Limitations**

Commence Packing




Apply Vacuum Bag



#### Modular Manufacturing – Advantages for Large Heatshields

- Optimal Number of Packing Technicians with Better Access
- **More Clock Time Available for High Quality Packing**
- Provides for Two (Pre-Cure) Vacuum-Bagging Steps (for Low Spots)
- **Allows Non-Destructive Inspection Before Bonding**
- Enables High-Tech Implementation (e.g., Dual-Layer Systems)
- Eliminates Risk of Loosing Entire Heatshield (e.g., Working Life)
- Facilitates Concurrent Production of Structure and Heatshield

MSL Backshell  
0.50-in. Thick H/C  
14.0 lb/ft<sup>3</sup> SLA Fill



2.65-m Aeroshell  
1.40-in. Thick H/C  
19.0 lb/ft<sup>3</sup> S-20 Fill

## MSL BACKSHELL PACKED BUT 0.5 IN. THK WITH 14 LB/FT<sup>3</sup> COMPOUND

MSL Backshell Packing at LMA  
SLA-561V Lightweight Ablator




“Phalanx” of Engineers/Technicians (16 in full photo)

2.65-m Module Packing at ABL  
SRAM-20 Midweight Ablator



Two Engineers/Technicians (optimal)

MSL Backshell  
0.50-in. Thick H/C  
14.0 lb/ft<sup>3</sup> SLA Fill





3.8 Times Mass Per Ft<sup>2</sup>

2.65-m Aeroshell  
1.40-in. Thick H/C  
19.0 lb/ft<sup>3</sup> S-20 Fill



## ABL 1.0-IN. LARGE-CELL HONEYCOMB MADE IN HOUSE FOR 2.65-M A/S


Process Includes Impregnating Fabric, Slitting into Ribbons, Shaping Ribbons, Assembly






## ABL PRODUCTION OF 2.65-M NOSE MOLD AND FITTING H/C PANEL

Mold for Nose Module Designed to Produce a Near-Net SRAM-20 Ablator Part




Rough Milling Base of Nose Mold



Thermally Stress Relieving Nose Mold Base



Fitting Honeycomb to Nose Mold






Close-Up of H/C in Nose Mold



## ABL PRODUCTION OF 2.65-M FLANK MOLD AND FITTING H/C PANELS





### Mold for Flank Modules Designed to Produce a Near-Net SRAM-20 Ablator Part





## 2ND MILLING DEFINES FLANK EDGES AND FINALIZES BOND SURFACE





All Eight Large Flank Modules Receive 5-Axis Milling on Both External and Bond Surface





## 2ND MILLING DEFINES NOSE EDGE AND FINALIZES BOND SURFACE

Single Large Nose Module Receives 5-Axis Milling on Both External and Bond Surface





## NINE SRAM-20 MODULES UNDERGOING FIT CHECKS BEFORE BONDING

**Ablator Module Bonding Done with Epoxy-Phenolic Film Adhesive for 2.65-m Aeroshell**






## FINAL COMPLETE FIT-CHECK OF NINE MODULES WITH GAP SPACERS

**Engineered Gap Spacers Used to Maintain Precise Gap Widths for Subsequent Filling  
SRAM-20 Ablator Used to Fill Gaps – Final Heatshield is 100% SRAM-20 !**



## BONDING NUMBER-2 SRAM-20 FLANK MODULE OF 2.65-M AEROSHELL

**Bonding Operations are Facilitated by Cold Laboratory Temperatures  
Inhibits/Maintains Tack of Film Adhesive to Workable Level**





## VACUUM-BAGGED AEROSHELL IN OVEN FOR CURING ABLATOR BOND

First Vac-Bag Oven Cycle is to Cure Film Adhesive that Bonds Modules to Structure  
Second Oven Cycle is to Cure SRAM-20 Ablator Compound Packed into Intermodule Gaps



## 2.65-M SRAM-20 HEATSHIELDED READY FOR FINAL 5-AXIS CNC MILLING

Intermodule Gaps Fully Packed and Cured Using SRAM-20 Ablator Compound  
Final Milling Requires Large DMS 5-Axis Milling Machine with 10-ft Bed







## DEVELOPING SEAM-PACKING PROCESS – PREPARING TEST SAMPLES

### Packing Process for Intermodule Seams Validated by Arc-Jet Aeroshear Testing

Seam Test  
Sample Plan  
26 Per Panel



Prepared Panel for Seam Packing




Applying Resin Wet Coat to Seams



Packing with Ablator Compound

## 56 PACKED-SEAM AND CONTROL SAMPLES FOR ARC-JET TESTING

Aeroshear Samples are 6.0 x 3.0 x 0.8 In.- Tested to MSL-Developed Shear Environments






## ALL SRAM-20 PACKED SEAMS SHOWED EXCELLENT PERFORMANCE

### Seam Locations Showed Same Performance as Standard SRAM-20 in Honeycomb


0-Deg. Seam in Test at  $128 \text{ W/cm}^2$  – 5.91 psf Shear (A1)




Stable Seam Response to Surface  
"Charring" Environment



18-Deg. Seam in Test at  $214 \text{ W/cm}^2$  – 7.84 psf Shear (3)



Stable Seam Performance to Surface  
"Melting" Environment





## CHAR-LAYER GROWTH AND PERFORMANCE FOR CHARRING ABLATOR

Charring Ablator Develops Insulating Surface Char Layer During Ablation Process  
SRAM-20 Silicone-Based Ablator has Optimal Performance to  $\sim 350 \text{ W/cm}^2$   
Above  $350 \text{ W/cm}^2$ , Char Layer is Thin – Low-Density Phenolic Ablator Better  
Arc-Jet Stagnation Test Series at NASA Ames Research Center

SRAM-20 Sample 3425 –  $128 \text{ W/cm}^2$  for 160 sec  
Surface Recession – 0.00 in.

SRAM-20 Sample 3424 –  $254 \text{ W/cm}^2$  for 60 sec  
Surface Recession – 0.33 in.




(New Millennium 5.0-In. Diameter Iso-Q Shaped Samples with Sandwich-Composite Substrates)



## FULLY ASSEMBLED & MILLED 2.65-m MODULAR SRAM-20 AEROSHELL


Eight SRAM-20 Flank Modules and One Nose Module with SRAM-20 Gap Filler Between Modules



Aeroshell Positioned on ABL's Large Five-Axis Milling Machine

## DISPLAY PLAN FOR 2.65-m MODULAR SRAM-20 AEROSHELL AT IPPW-10

Photo Below Shows Aeroshell at Lawrence-Livermore Labs for Full-Up CT-Scan Testing



Aeroshell Mounted to Lid of Shipping Container