



Vented Airbags a new promising technology for Mars landers

G. Giovangrossi

26/3/2





SUMMARY

- ✓ Initial ExoMars Requirements in 2006
- ✓ Vented vs Non Vented Airbag
- ✓ New Vented Airbag Design for a 600kg Lander in 2008
- ✓ New Vent Control Logic
- ✓ Vent Test in Vacuum Chamber
- ✓ Inflation Test in Vacuum Chamber
- ✓ Material testing and compatibility with DHMR process
- √ Conclusions





Initial ExoMars Requirements in 2006

Lander mass:

Vertical velocity at impact:

Horizontal velocity at impact:

Lander attitude at impact:

Terrain slope:

Rock clearance:

Max deceleration at impact:

480 kg

12 m/s

9 m/s

± 12 deg

± 18 deg/

0.5 m

40 g_E











Vented Airbag



FUNCTIONAL SEQUENCE

- Airbag inflation and restraint release
- Cushioning transfers kinetic energy to the inflation gas
- Gas is vented to the atmosphere (careful control of vent timing to avoid turnover)
 - Final short freefall to the ground

DESIGN

- · Torus with hexagon plan form
- Elliptic section
- Segment volume of 2 m³ (12 m³ total)
- Segments divided by internal bulkheads and connected by small cross vent orifices
- Each segment vents independently through a vent valve
- Vent Control Unit based on laser sensors
- Petal type valve









Vented Airbag



11:38



Vented Airbag







Non Vented Airbag



FUNCTIONAL SEQUENCE

- 1. Airbag inflation and restraint release
- 2. Cushioning transfers kinetic energy to the inflation gas
- 3. Several rebounds reduce kinetic energy to zero
- 4. ABS retraction
- 5. LP petals opening and rover egress

DESIGN

- Set of four billiard ball rack airbags (geometrically the same)
- Each airbag is a six lobes with 2m diameter
- Airbag petal volume 16.2 m³ => total volume 64.8 m³



Non Vented Airbag







Vented vs Non Vented







New ExoMars Requirements in 2008

Lander mass:

Vertical velocity at impact:

Horizontal velocity at impact:

Lander attitude at impact:

Terrain slope:

Rock clearance:

Max deceleration at impact:

600 kg

10 m/s

3 m/s

± 12 deg

± 18 deg/

0.5 m


40 g_E








New Vent Control Logic Vent Control System








New Vent Control Logic





DYNA Model Correlation








24_03_2009_CAM_LATERALE.MOV



DYNA Model Example (Mars)

LS-DYNA USER INPUT



<u>۔</u> ب<mark>ل</mark>ئ





Vent Test in Vacuum Chamber

Verify the valve thermodynamic performances in sonic regime


Verify the overall valve delay before gas discharging

Get all the data needed to obtain a good LS-Dyna model correlated to the Mars environment



AERO SEKUR


Vent Test in Vacuum Chamber







Vent Test in Vacuum Chamber





AERO SEKUR

Inflation Test in Vacuum Chamber

Inflation System BB

Airbag in folded configuration





Inflation pressure of 112 barg in order to reach 160 mbar inside the segment

Helium gas used



AERO SEKUR

Inflation Test in Vacuum Chamber



Inflation system flange detachment from airbag fabric

Valve tube (in nylon film) burst due to the IS jet effect





Inflation Test in Vacuum Chamber







Property of Aero Sekur S.p.A. All rights reserved. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage or retrieval system, without permission in writing from the copyright holder.



Inflation Test in Vacuum Chamber






Inflation Test in Vacuum Chamber








Airbag Fabric Definition and Tests







Airbag Fabric Definition and Tests




Elementary Tests

Configuration to be tested:

- Config1: 1 bladder + 1 abrasion layer
- Config2: 1 bladder + 2 abrasion layer
- Config3: 1 bladder + 3 abrasion layer

Parameters:

- Ft= 100N (2D traction force representative of ABS membrane stress)
- R= 2mm (rock curvature radius)
- α = 60° (rock aperture angle)
- Fp_config1= 4153 N (average penetration force)
- Fp_config2= 4664 N (average penetration force)
- Fp_config3= 4818 N (average penetration force)







Airbag Fabric Compatibility with DHMR

The sterilization activity has been performed in the ESTEC Dry Heat Sterilizer

- Number of cycles: three
- > Duration of each: 30 hours
- > Initially delay:
 - Cycle 1: 4 hours 56 minutes
 - Cycle 2: 3 hours 15 minutes
 - Cycle 3: 3 hours 18 minutes
- > Temperature: 130 °C
 - Max: 130.24 °C • Min: 124.99 °C
- Packing density: 175 kg/m³
- > Temperature Sensors:
 - three thermocouples
 - · chemical indicators
- Bio-indicators:
 - · Geobacillus stearothermophilus
 - · Bacillus athrophaeus









Airbag Fabric Compatibility with DHMR

The test has been performed twice, after the first and second cycle.


After sterilization pieces (5x5 cm) of materials and bio-indicators have been put into Petri dishes and covered with TSA-Agar

The dishes have been incubated for 96h (checked after 24, 48, 72 hours).

Cycle 1		
Bacteria	Location	count
GS	Bottom	1
GS	Bottom	1
GS	Bottom	0
BA	Bottom	0
BA	Bottom	0
BA	Bottom	0
GS	Middle	0
GS	Middle	0
GS	Middle	0
ВА	Middle	0
BA	Middle	0
BA	Middle	0
GS	Тор	0
GS	Тор	0
GS	Тор	0
BA	Тор	0
BA	Тор	0
BA	Тор	0
GS + control		uncountable
BA+		
control		uncountable

Cycle 2		
Bacteria	Location	count
GS	Bottom	0
GS	Bottom	0
GS	Bottom	0
BA	Bottom	0
BA	Bottom	0
BA	Bottom	0
GS	Middle	1
GS	Middle	1
GS	Middle	2
BA	Middle	0
BA	Middle	0
BA	Middle	0
GS	Тор	2
GS	Тор	1
GS	Тор	1
BA	Тор	0
ВА	Тор	0
ВА	Тор	0
GS +		
control		uncountable
BA +		unasuntable
control		uncountable






GS = Geobacillus stearothermophilus BA = Bacillus athropheus



CONCLUSIONS (1/2)







CONCLUSIONS (2/2)

Vented Airbag Technology (to be used for Mars Landing) needed development:

Inflation and Drop test verification in representative Mars ambient conditions



THANKS FOR

YOUR ATTENTION