


## A Sample Handling, Encapsulation, and Containerization Subsystem Concept for Mars Sample Caching Missions




**7<sup>th</sup> International Planetary Probe Workshop  
Barcelona, Spain**

Paulo Younse, Curtis Collins, Paul Backes  
Jet Propulsion Laboratory  
California Institute of Technology


17 June 2010


The subject matter in this paper is pre-decisional, and for discussion purposes only.



# Outline

- **Sample Caching for Mars Sample Return**
- **Integrated Mars Sample Acquisition & Handling (IMSAH)**
- **Previous Mars Caching Concepts**
- **Sample Handling, Encapsulation & Containerization System (SHEC)**
- **SHEC Animation**
- **SHEC Prototype**
- **Conclusion**





# Sample Caching for Mars Sample Return

Integrated Mars Sample Acquisition & Handling (IMSAH)

- **Why Mars?**


- “Mars has crustal and atmospheric characteristics that make it a priority exploration target for understanding the origins of life”
- “Essential energy, water, and nutrient requirements to support and sustain life are currently present and the Martian geologic record offers tantalizing clue of many ancient habitable environments”
- “If life emerged and evolved on early Mars then it is possible, and indeed likely, that physical or chemical biosignatures are preserved in the exposed rock record”

- **Focus of Missions:**

- Follow the Water (ODY, MER, MEX, MRO, PHX)
- Habitable Environments (MSL, MAVEN, TGM, EXM)
- Seek Signs of Life (MAX-C, MSR)

- **Motivation for Mars Samples:**

- “Significantly increase our understanding of atmospheric, biologic, and geologic processes occurring there, as well as permit evaluation of the hazards to humans on the surface”
- Scientific analysis could be done without the limited instrument payload and operational resources of the rover or lander
- Samples could be distributed amongst international laboratories and the science community
- Samples could be preserved for analysis with future instruments




Ref: Mars Astrobiology Explorer-Cacher (MAX-C): A Potential Rover Mission for 2018, Final Report of the Mars Mid-Range Rover Science Analysis Group, 2009.  
MEPAG Next Decade Science Analysis Group, “Science Priorities for Mars Sample Return,” *Astrobiology*, Vol. 8, No. 3, 2008.

17/6/2010

The subject matter in this paper is pre-decisional, and for discussion purposes only.


PGB, 3






# Potential Mars Mission Timeline

Integrated Mars Sample Acquisition & Handling (IMSAH)






Ref: Kazz, G., NASA Mars Program, Future Mars Mission Plans/Scenarios, 2009.




# Mars Astrobiology Explorer-Cacher (MAX-C)

Integrated Mars Sample Acquisition & Handling (IMSAH)

- **Proposed Mars Astrobiology Explorer-Cacher (MAX-C):**
  - Mid-size rover expected around 300 kg
  - Proposed for 2018 launch window alongside ESA's ExoMars rover using MSL-like EDL
  - Instruments for remote and contact science, as well as coring rocks
  - Baseline a sample caching subsystem for encapsulating rock cores for potential future return



Ref: Salvo, C. and Elfving, A., "Proposed Mars Astrobiology Explorer – Cacher (MAX-C) & ExoMars 2018 (MXM-2018) Mission Formulation Status, *Jet Propulsion Laboratory, California Institute of Technology*, Presented at the 22<sup>nd</sup> MEPAG Meeting, Monrovia, CA, Mar. 17-18, 2010.







# Integrated Mars Sample Acquisition & Handling (IMSAH)


Integrated Mars Sample Acquisition & Handling (IMSAH)

- **Integrated Mars Sample Acquisition & Handling (IMSAH) Task at JPL**

- 3-year Jet Propulsion Laboratory RT&D task initiated in FY '09
- **Objective:** Develop and validate to TRL 4 an integrated core and soil sample acquisition and caching system suitable for use on a 300kg MER-class Mars rover
- **Target Mission:** 2018 MAX-C
- **Schedule:**
  - FY '09: Trade space and concept development
  - FY '10: TRL 4 hardware development
  - FY '11: TRL 4 integrated validation on a rover










# Previous Mars Caching Concepts

Integrated Mars Sample Acquisition & Handling (IMSAH)

## ATHENA Rover Caching Concept (1999)

- Proposed for MSR 03/05
- Rotary drag mini-corer capable of taking 50-60 cores of 8 mm wide by 25 mm in length
- Limited ability to compensate for rover slip
- Raw core ejection risk with broken cores
- Requires dropping off samples into OSC
- Not flown; rover evolved into MER






# Previous Mars Caching Concepts


Integrated Mars Sample Acquisition & Handling (IMSAH)

## Mars Science Laboratory Caching Concept (2008)

- Single cache container capable of accepting 5-10 rock samples 0.5-1.5 cm across
- Open to Mars environment
- Grasping feature for a manipulator on a future fetch rover to remove it from MSL
- Tabs holding container to the cradle bend away when the container is pulled out
- Not included in final configuration due to rover design issues and debated science value




Removal feature for future sample return rover



Ref: Karcz, J. S. et al., "The Implementation of the Mars Science Laboratory Sample Cache," *Ground Truth from Mars: Science Payoff from a Sample Return Mission*, Lunar Planetary Institute, Albuquerque, NM, Apr. 21-23, 2008.


The subject matter in this paper is pre-decisional, and for discussion purposes only.






# JPL IMSAH Caching Concept

Integrated Mars Sample Acquisition & Handling (IMSAH)





- **Caching Subsystem:**
  - **Sample Encapsulation:** Sample acquisition directly into the sample tube in the bit
  - **Sample Transfer:** Bit changeout for transferring sample to caching subsystem (sample in tube in bit)
  - **Functions:** Sample tube transfer in/out of bit, bit changeout, tube sealing, tube storage in canister
- **Tool Deployment Device:**
  - **Design:** 5 DOF arm
  - **Functions:** Tool deployment, alignment and linear feed; canister placement on the ground
- **Sample Acquisition Tool:**
  - **Technique:** Rotary percussion
  - **Functions:** Coring, breakoff, retention, bit changeout, linear spring for preload and vibration isolation



# Sample Transfer Interactions


Integrated Mars Sample Acquisition & Handling (IMSAH)





# Movie, Operational Sequence

Integrated Mars Sample Acquisition & Handling (IMSAH)




[Video Link](#)

17/6/2010

The subject matter in this paper is pre-decisional, and for discussion purposes only.


PGB, 11





# Caching Subsystem – Sample Handling, Encapsulation and Containerization Concept


Integrated Mars Sample Acquisition & Handling (IMSAH)






# SHEC Handling Arm Stations


Integrated Mars Sample Acquisition & Handling (IMSAH)





# SHEC Animation

Integrated Mars Sample Acquisition & Handling (IMSAH)



[Video Link](#)


[Quicktime Video](#)

PGB, 14

17/6/2010


The subject matter in this paper is pre-decisional, and for discussion purposes only.





# Bringing the Samples Back to Earth

Integrated Mars Sample Acquisition & Handling (IMSAH)




Credit: NASA JPL/Caltech

17/6/2010





The subject matter in this paper is pre-decisional, and for discussion purposes only.


PGB, 15



# SHEC – Alternate Layouts







Integrated Mars Sample Acquisition & Handling (IMSAH)

Configuration	Layout	Number of Bits	Number of Tubes	Comments
Full Version		6	31 sample tubes 31 plugs 24 spare tubes 17 spare plugs	Large sample storage, large bit storage, most room for drill interface
Reduced Bit Carousel		4	31 sample tubes 31 plugs 24 spare tubes 17 spare plugs	Large sample storage
<b>Reduced Bit and Canister Carousel</b>		4	19 sample tubes 19 plugs 2 spare tubes 2 spare plugs	Smallest footprint
Single-Combined Carousel		4	19 sample tubes 19 plugs 11 spare tubes 11 spare plugs	Requires 1 less actuator, least room for drill interface




# SHEC – Multiple Canisters

Integrated Mars Sample Acquisition & Handling (IMSAH)


Configuration	Layout	Number of Tubes
<b>Single Canister</b> 		19 sample tubes 19 plugs 2 spare tubes 2 spare plugs
<b>Dual Canister</b> 		38 sample tubes 38 plugs 4 spare tubes 4 spare plugs
<b>Triple Canister</b> 		57 sample tubes 57 plugs 6 spare tubes 6 spare plugs







# SHEC – Flexible Bit Interface

Integrated Mars Sample Acquisition & Handling (IMSAH)




**Angled bit carousel could allow variation in orientation of coring tool docking for bit changeout**






# SHEC Proof-of-Concept Prototype (2009)


Integrated Mars Sample Acquisition & Handling (IMSAH)






# SHEC TRL 4 Prototype in Development (2010)

Integrated Mars Sample Acquisition & Handling (IMSAH)










# Conclusions

- A Sample Handling, Encapsulation, and Containerisation (SHEC) subsystem capable of sample caching functions for proposed future Mars sample caching missions such as MAX-C is being developed through the IMSAH task at the Jet Propulsion Laboratory.
- SHEC System Benefits:
  - Utilizes bit change-out to insert/remove sample tubes into bits
  - Collects samples directly into tube
    - Reduces contamination risks
    - Increases robustness to broken cores
  - Enables storage of tubes in a close-packed canister compatible with current Mars Sample Return architectures
  - Could lead to a simplified/lighter drill without the need for a push rod
- Flexibility in the design:
  - Expansion for samples tubes and bits
  - Additional sample canisters
  - Angle bit carousel
- Proof-of-concept prototype built and tested
- TRL 4 level design currently in development









## Backup Slides




# Caching System Option Space

Integrated Mars Sample Acquisition & Handling (IMSAH)

		Robustness to Broken Cores		Close Packing		Sample Contamination		Mass (consider system mass)	
Direct Core Transfer		Low, transfers raw core	↓	Transfer with large arm limits precision	↓	More exposed, increases risk	↓	Low mass, but drill needs a push rod	↔
Indirect Core Transfer		Low, transfers raw core	↓	Transfer with small arm increases precision	↑	Less exposed, decreases risk	↑	Medium mass, but drill needs a push rod	↓
Direct Tube Transfer		High, transfers tube	↑	Transfer with large arm limits precision	↓	More exposed, increases risk	↓	Low mass, but drill needs a push rod and tube gripper	↔
Indirect Tube Transfer		High, transfers tube	↑	Transfer with small arm increases precision	↑	Less exposed, decreases risk	↑	Medium mass, reduces drill functions (mass)	↔








# Sample Acquisition and Caching: Operational Sequence

Integrated Mars Sample Acquisition & Handling (IMSAH)


1. Sample Handling, Encapsulation and Containerization (SHEC) caching subsystem retrieves a new tube and puts it in a bit and rotates the bit to the bit port.
2. Tool Deployment Device (TDD) positions Sample Acquisition Tool (SAT) at SHEC bit port and SAT engages bit.
3. TDD deploys SAT to rock.
4. SAT acquires, breaks off, and retains a core directly into a sample tube in the bit.
5. TDD transports SAT to SHEC caching subsystem and inserts coring bit into SHEC bit port.
6. Bit is released by SAT and engaged by SHEC.
7. SHEC removes tube from bit, seals the tube, and stores the tube in the canister.
8. Ready to acquire another core sample.






# Sample Encapsulation


Integrated Mars Sample Acquisition & Handling (IMSAH)






# Sample Encapsulation

Integrated Mars Sample Acquisition & Handling (IMSAH)









# Sample Encapsulation



Integrated Mars Sample Acquisition & Handling (IMSAH)






# Bit Changeout


Integrated Mars Sample Acquisition & Handling (IMSAH)






# Canister Removal

Integrated Mars Sample Acquisition & Handling (IMSAH)








# Sample Canister


Integrated Mars Sample Acquisition & Handling (IMSAH)






# Canister Tube Configuration Options\*

Integrated Mars Sample Acquisition & Handling (IMSAH)



\* Sample canister with 13 mm holes for 10 mm samples, with ~.75 mm min wall thickness between holes






# Bringing the Samples Back to Earth

Integrated Mars Sample Acquisition & Handling (IMSAH)

## Possible Mars Sample Return Mission Storyboard



Credit: NASA JPL/Caltech